

6.2 WITHDRAWAL TRANSACTION




Step 1

Insert the card.




Step 2

Enter the pin number and press the “ENTER” key.



Step 3

Press the “WITHDRAWAL” screen key.




Step 4

If a “SURCHARGE” option is enabled, the “SURCHARGE” screen will be displayed. Select “YES” to continue, or “NO” to cancel.




Step 5

If “YES” is selected, the following screen will be displayed. Select the desired option.




Step 6

Select the desired amount to be withdrawn. If the desired amount is not displayed, select the “OTHER” screen key.



Step 7

After the desired amount is entered, the ATM dials the processor and requests approval for the transaction. When authorization is received from the processor, the cash will be dispensed.



Step 8

After dispensing cash, a receipt will be printed.